





obtained by use of a lock. Examples of additional safety measures include the removal of an isolating circuit element, blocking of a controlling switch, or opening of an extra disconnecting device.

1910.333(b)(2)(iii)(E) A lock may be placed without a tag only under the following conditions:

1910.333(b)(2)(iii)(E)(1) Only one circuit or piece of equipment is deenergized, and

1910.333(b)(2)(iii)(E)(2) The lockout period does not extend beyond the work shift, and

1910.333(b)(2)(iii)(E)(3) Employees exposed to the hazards associated with reenergizing the circuit or equipment are familiar with this procedure.

1910.333(b)(2)(iv) Verification of deenergized condition. The requirements of this paragraph shall be met before any circuits or equipment can be considered and worked as deenergized.

1910.333(b)(2)(iv)(A) A qualified person shall operate the equipment operating controls or otherwise verify that the equipment cannot be restarted.

1910.333(b)(2)(iv)(B) A qualified person shall use test equipment to test the circuit elements and electrical parts of equipment to which employees will be exposed and shall verify that 2.88 (r)3. g (i610.91e 75 v -2)-3